



AMERICA/  
SPEEDMASTER



**QUICK RELEASE ROADSTER SCREEN (21.5") - AMERICA** ✂ 0.1  
54cm high "look through" Roadster Screen. Manufactured from lexan polycarbonate. Features Quantum coating offering improved scratch resistance with optical clarity. Requires Mounting Kit A9708237 for fitment.

**A9701262**



**QUICK RELEASE SUMMER SCREEN - AMERICA** ✂ 0.1  
29cm high "look over" Summer Screen. Manufactured from lexan polycarbonate. Features Quantum coating offering improved scratch resistance with optical clarity. Requires mounting kit A9708237 for fitment.

**A9701251**



**SCREEN MOUNTING KIT - AMERICA** ✂ 0.5  
Facilitates fitment of America quick release screens A9701218 or A9701251.

**A9708237**



**QUICK RELEASE ROADSTER SCREEN - SPEEDMASTER** ✂ 0.1  
47cm high "look through" Roadster Screen. Manufactured from lexan polycarbonate. Features Quantum coating offering improved scratch resistance with optical clarity. Requires Mounting Kit A9708238 and Indicator Relocation Kit A9838004 for fitment.

**A9701219**



**SCREEN MOUNTING KIT - SPEEDMASTER** ✂ 0.5  
Facilitates fitment of Speedmaster quick release screens A9701218 or A9701251.

**A9708238**



**LONGHAUL BACKREST PAD - PASSENGER** ✂ 0.2  
Offered for use with A9758149. Pad fabric matches accessory seats.

**A9708239**



**QUICK RELEASE SUMMER SCREEN - SPEEDMASTER** ✂ 0.1  
33cm high "look over" Summer Screen. Manufactured from lexan polycarbonate. Features Quantum coating offering improved scratch resistance with optical clarity. Requires Mounting Kit A9708238 and Indicator Relocation Kit A9838004 for fitment.

**A9701252**



**SCREEN LOCK KIT** ✂ 0.2  
Stainless steel screen lock kit for use with America and Speedmaster quick release screens. Supplied with two keys and anti-tamper mounting fasteners.

**A9708250**



**TOURING BACKREST PAD - PASSENGER** ✂ 0.2  
Offered for use with A9758149. Pad fabric matches OE seat.

**A9708240**



#### LEATHER SADDLEBAGS - LARGE

Genuine Leather saddlebags with embossed Triumph branding and chrome plated buckles with convenient hidden clips. Supplied with all mounting hardware. 18 Litre capacity per bag.

**A9508159**

✂ 0.7



#### LOW GEL SEAT - AMERICA

25mm lower than standard. Gel insert for long distance comfort.

**T2305817**

✂ 0.1



#### LOW GEL SEAT - SPEEDMASTER

25mm lower than standard. Gel insert for long distance comfort.

**T2305815**

✂ 0.1



#### TALL SISSY BAR

Shown installed with optional luggage rack, A9758169.

**A9758167**

✂ 0.5



#### SHORT SISSY BAR

Shown installed with optional luggage rack, A9758169.

**A9758168**

✂ 0.5



#### LONGHAUL SISSY BAR KIT

Larger Sissy Bar for 2011MY Speedmaster and America Models only. Requires backrest pad for fitment. Optional luggage rack also available.

**A9758149**

✂ 0.5



#### LONGHAUL SISSY BAR RACK KIT

Optional Luggage Rack for use with Sissy Bar Kit A9758149.

**A9758161**

✂ 0.2



#### LUGGAGE RACK - CHROME

Traditional luggage rack for America and Speedmaster. Also available via sissy bar and rack kits A9758167 & A9758168.

**A9758169**

✂ 0.2



#### FRONT SPOILER KIT - PAINTED

Finished in all available colours and supplied complete with all mounting hardware.

**A9708246-##**

✂ 0.4



**HI-FLOW CHROME SILENCERS\*** ✂ 0.7  
Provides improved tonal quality. Sold with dedicated engine tune to guarantee optimum performance. Offered for off road use only.  
**A9608138**



**HI-FLOW CHROME SILENCERS - SHORT\*** ✂ 0.7  
Provides improved tonal quality. Sold with dedicated engine tune to guarantee optimum performance. Offered for off road use only.  
**A9608139**



**HI-FLOW CHROME SILENCERS - LONG\*** ✂ 0.7  
Provides improved tonal quality. Sold with dedicated engine tune to guarantee optimum performance. Offered for off road use only.  
**A9608140**



**LIFTER ARM COVER - CHROME** ✂ 0.1  
High gloss chrome alternative to standard part.  
**A9738075**



**"CHROME LINE" RIDER FOOTBOARD KIT** ✂ 0.2  
High quality chromed teardrop rider footboards and rubber mats with chrome detailing. Requires A9778001 for fitment.  
**A9758158**



**"CLASSIC" RIDER FOOTBOARD KIT** ✂ 0.2  
High quality chromed teardrop rider footboards and rubber mats. Requires A9778001 for fitment.  
**A9758157**



**"CHROME LINE" PASSENGER FOOTBOARDS** ✂ 0.2  
High gloss chromed passenger footboards featuring Chromeline detailing. Requires A9778000 for fitment.  
**A9758160**



**"CLASSIC" PASSENGER FOOTBOARDS** ✂ 0.2  
High gloss chromed passenger footboards. Requires A9778000 for fitment.  
**A9758159**



**"CHROME LINE" RIDER FOOTPEG KIT** ✂ 0.1  
Alternative footpegs featuring the Chromeline theme.  
**A9770014**



**RIDER FOOTBOARD MOUNTING KIT** ✂ 0.8  
Facilitates fitment of Classic or Chromeline Rider Footboards.  
**A9778001**



**PASSENGER FOOTBOARD MOUNTING KIT** ✂ 0.4  
Facilitates fitment of Classic or Chromeline Passenger Footboards.  
**A9778000**



**FOOT CONTROLS KIT** ✂ 0.5  
Alternative foot controls kit ideal for use with Classic/Chromeline Rider Footboards.  
**A9778007**

\* Please refer to the rear cover for further information



**INDICATOR RELOCATION KIT** ✂ 0.3  
Relocates indicators for fitment with auxiliary/fog lamps on Speedmaster.  
**A9838004**



**AUXILIARY LAMP KIT - AMERICA** ✂ 0.8  
Additional illumination styled seamlessly with the Triumph America.  
**A9838002**



**AUXILIARY LAMP KIT - SPEEDMASTER** ✂ 0.8  
Additional illumination with a high gloss chrome finish. Requires indicator relocation kit A9838004 for fitment.  
**A9838006**



**HEADLAMP VISOR CHROME** ✂ 0.2  
High quality chrome plated headlamp visor.  
**A9738067**



**LEATHER EMBELLISHER - CHROME** ✂ 0.1  
Secured via pin fastener.  
**A9938098**



**LEATHER EMBELLISHER - CHROME SELF ADHESIVE** ✂ 0.1  
Self adhesive.  
**A9938097**



**ENGINE DRESSER BARS - CHROME** ✂ 0.5  
Facilitates fitment of highway pegs mounts.  
**A9758059**



**NUMBER PLATE BRACKET - CHROME** ✂ 0.1  
High gloss chrome alternative to standard part.  
**A9738168**



**ADJUSTABLE HIGHWAY PEG MOUNTS** ✂ 0.3  
For use with Triumph highway pegs. Provides 360 degrees of adjustment.  
**A9750455**



**SHORT HIGHWAY PEG MOUNT** ✂ 0.2  
For use with Triumph highway pegs.  
**A9750463**



**HIGHWAY PEGS - LOGO BADGE** ✂ 0.2  
Features rubber foot grip and Triumph logo. Requires Engine Dresser Bars A9758059 for fitment. Requires Mounting Kit A9750455 or A9750463 for fitment.  
**A9750459**



**"CHROME LINE" HIGHWAY PEGS** ✂ 0.2  
Features rubber foot grip and Chromeline detailing. Requires Engine Dresser Bars A9758059 for fitment. Requires Mounting Kit A9750455 or A9750463 for fitment.  
**A9750523**



**CLUTCH COVER FINISHER**  
Standard equipment on Speedmaster.  
**A9938045**

✂ 0.1



**CHAIN GUARD - CHROME**  
High gloss chrome alternative to standard part.  
**A9758166**

✂ 0.4



**REAR BRAKE RESERVOIR COVER - CHROME**  
High gloss finisher for the rear brake reservoir.  
**A9730121**

✂ 0.1



**BATTERY BOX COVER - CHROME**  
High gloss chrome alternative to standard part.  
**A9730186**

✂ 0.4



**TEARDROP MIRRORS - DRILLED STEM**  
High gloss chrome mirrors featuring laser etched Triumph logo and drilled stem detail.  
**A9638034**

✂ 0.2



**TEARDROP MIRRORS**  
High gloss chrome mirrors featuring laser etched Triumph logo.  
**A9638033**

✂ 0.2



**OVAL MIRRORS**  
High gloss chrome mirrors featuring laser etched Triumph logo.  
**A9638031**

✂ 0.2



**OVAL MIRRORS - DRILLED STEM**  
High gloss chrome mirrors featuring laser etched Triumph logo and drilled stem detail.  
**A9638032**

✂ 0.2



**TEARDROP MIRRORS - BLACK**  
Tapered Teardrop Style. Satin Black finish. Fits all Triumph Cruisers.  
**A9638085**

✂ 0.2



**OVAL MIRRORS - BLACK**  
Satin Black finish. Fits all Triumph Cruisers.  
**A9638084**

✂ 0.2



**CAM COVER - CHROME**  
High gloss chrome alternative to standard part.  
**A9618128**

✂ 1.0



**KNEE PADS**  
Self adhesive rubber tank pads protect contact points on the tank from wear.  
**A9718010**

✂ 0.2



**TACHO CONVERSION KIT** ✂ 0.5  
Tacho conversion kit for America models.  
Vin specific consult electronic parts catalogue for details.  
**A9828006**



**TRIUMPH D LOCK** ✂ 0.0  
High quality, 270mm D lock. ART\*\*\*\*, FFMC, Sold Secure Gold, NK Test & SRA approved.  
**A9810006**



**AXLE NUT COVERS - CHROME** ✂ 0.1  
Chrome axle nut covers provide a smooth finish to front and rear wheel spindles. Four finishers per kit.  
**A9738050**



**LEATHER TANK COVER** ✂ 0.1  
Genuine Leather Tank Cover featuring subtle Triumph branding and convenient front mounted pocket.  
**A9520079**



**PAINT PROTECTION KIT** ✂ 1.0  
Super strong clear film protects high contact area's from wear. Manufactured by class leaders 3M.  
**A9930327**



**TRIUMPH DISC LOCK** ✂ 0.0  
High quality, forged disc lock and nylon branded carry pouch. ART\*\*\*\*, Sold Secure Gold & SRA approved.  
**A9810000**



**ALARM IMMOBILISER** ✂ 1.0  
Thatcham approved (Category 1) bespoke alarm immobiliser system developed in conjunction with Datatool. Supplied with 2 x waterproof Alarm fob's which can be integrated with ignition key.  
**A9808085**



**AUXILIARY POWER SOCKET** ✂ 0.1  
Auxiliary Power Socket for use with Optimate Adaptor, A9930011.  
**A9938015**



**CLUTCH CABLE GUIDE BRACKET** ✂ 0.0  
CNC Machined replacement clutch cable guide bracket with laser etched logo branding.  
**A9610531**



**CNC MACHINED CHOKE KNOB** ✂ 0.0  
CNC machined replacement choke knob with laser etched logo branding.  
**A9610532**



**CNC MACHINED OIL FILLER CAP** ✂ 0.0  
CNC machined replacement oil filler cap with laser etched logo branding.  
**A9610533**



**CNC MACHINED THROTTLE BODY CAPS** ✂ 0.0  
CNC machined replacement throttle body caps with laser etched logo branding.  
**A9610534**