

Brake Pads

HONDA			
Model	Year	Front	Rear
CR 80	86-91	99-077	Drum
CR 80	92-01	99-007	99-003
CR 80	2002	99-007	99-003
CR 85	03-07	99-007	99-003
CRF 150	07-	99-007	99-176
CR 125	84-86	99-102	Drum
CR 125	87-94	99-004	99-003
CR 125	95-01	99-041	99-003
CR 125	02-07	99-041	99-176
CR 250	84-86	99-102	Drum
CR 250	87-94	99-004	99-003
CR 250	95-01	99-041	99-003
CR 250	02-07	99-041	99-176
CRF 250R	04-	99-041	99-176
CRF 250X	08-	99-041	99-176
CRF 450R	02-	99-041	99-176
CRF 450X	05-	99-041	99-176
CR 500	84-86	99-102	Drum
CR 500	87-94	99-004	99-003
CR 500	95-01	99-041	99-003
XR 250	88-89	99-004	Shoes
XR 250	90-95	99-004	99-003
XR 250	96-07	99-041	99-003
XR 400	96-07	99-041	99-003
XR 500	83-84	99-102	Drum
XR 600	85-87	99-102	Drum
XR 600	88-90	99-004	Drum
XR 600	91-92	99-004	99-003
XR 600	93-08	99-041	99-003
XR 650	00-	99-041	99-003