

# Brake Pads

HUSQVARNA			
Model	Year	Front	Rear
CR 50	2005	99-173	Drum
CR 50 Pro	2005	99-173	99-190
CR/SM 50	11-	99-190	99-190
CR 65	11-	99-185	99-297
TE 100	2005	99-173	Drum
CR 125	84-85	99-038	Drum
CR 125	86	99-038	99-038
CR 125	87-89	99-006	99-038
CR 125	90-91	99-006	99-005
CR 125	92-94	99-002	99-007
CR 125	95-04	99-031	99-023
CR 125	05-	99-031	99-191
WR 125	84-86	99-038	Drum
WR 125	87-89	99-006	99-038
WR 125	90-91	99-006	99-005
WR 125	92-94	99-002	99-007
WR 125	95-05	99-031	99-023
WR 125	06-	99-031	99-191
CR 250	84-86	99-038	Drum
CR 250	87-89	99-006	99-038
CR 250	90-91	99-006	99-005
CR 250	92-94	99-002	99-007
CR 250	95-04	99-031	99-023
CR 250	05-	99-031	99-191
WR 250	84-86	99-038	Drum
WR 250	87-89	99-006	99-038
WR 250	90-91	99-006	99-007
WR 250	92-94	99-002	99-007
WR 250	95-05	99-031	99-023
WR 250	06-	99-031	99-191
WR 300	09-	99-031	99-191
TE 300	11-	99-031	99-191

HUSQVARNA			
Model	Year	Front	Rear
TE 310	09-	99-031	99-191
TE 350	92-94	99-002	99-007
TE 350	95-98	99-031	99-023
WR 360	92-94	99-002	99-007
WR 360	95-04	99-031	99-023
WR 400	85-86	99-038	Shoes
TE 400	95-96	99-031	99-023
Auto 430	87-88	99-038	Drum
CR 430	87-88	99-038	Drum
TE 410	96-00	99-031	99-023
TE 450	02-05	99-031	99-023
TE 450	06-10	99-031	99-191
TC 450	02-03	99-031	99-023
TC 450	05-10	99-031	99-191
CR 500	84-86	99-038	Drum
CR 500	87-89	99-006	Drum
TC 500	86-87	99-038	Drum
TC 510	88-90	99-006	Drum
TE 510	84-86	99-038	Drum
TE 510	87-89	99-006	Drum
TE 510	90-91	99-006	99-005
SMR 511	11-	-	99-191
TE 511	11-	99-031	99-191
TC 570	01-02	99-031	99-023
TE 570	01-04	99-031	99-023
TE 570	09-	99-031	99-191
TC 610	91	99-006	99-005
TC 610	92-94	99-002	99-007
TC 610	96-00	99-031	99-023
TC 610	06-09	99-031	99-023
TE 610	91-95	99-006	99-005
TE 610	96-09	99-031	99-023
TE 630	10-	99-031	99-191