

# Brake Pads

YAMAHA			
Model	Year	Front	Rear
YZ 80	86-92	99-034	Drum
YZ 80	93-01	99-034	99-077
YZ 85	02-	99-034	99-077
TTR 125	00-	99-034	Drum
YZ 125	85-87	99-043	Drum
YZ 125	1988	99-043	99-018
YZ 125	1989	99-002	99-077
YZ 125	1990	99-002	99-001
YZ 125	91-96	99-002	99-100
YZ 125	97-02	99-041	99-003
YZ 125	03-07	99-041	99-187
YZ 125	08-	99-248	99-187
YZ 250	85-87	99-043	Drum
YZ 250	88	99-043	99-018
YZ 250	89	99-002	99-077
YZ 250	90	99-002	99-001
YZ 250	91-96	99-002	99-100
YZ 250	97-02	99-041	99-003
YZ 250	03-07	99-041	99-187
YZ 250	08-	99-248	99-187
YZ 360	89-91	99-002	99-077
YZ 250F	01-02	99-041	99-003
YZ 250F	01-02	99-041	99-187
YZ 250F	03-06	99-041	99-187
YZ 250F	07-	99-248	99-187
YZ 400F	97-99	99-041	99-003
YZ 426F	00-02	99-041	99-003
YZ 450F	03-07	99-041	99-187
YZ 450F	08-	99-248	99-187
YZ 490	85-90	99-043	Drum

YAMAHA			
Model	Year	Front	Rear
WR 200	91-92	99-002	99-100
WR 250	1989	99-002	99-077
WR 250	90-96	99-002	99-100
WR 250	1997	99-002	99-001
WR 250	98-04	99-041	99-003
WR 250F	01-02	99-041	99-003
WR 250F	03-	99-041	99-187
WR 400F	98-99	99-041	99-100
WR 426F	00-02	99-041	99-003
WR 450F	03-	99-041	99-187
WR 500	91-93	99-002	99-018